

How to mount an "Xtreme Wall Mount" onto your wall.

The frame has 8 holes on the back that must be fastened to the wall with the screws and washers included. Longer screws of similar diameter can be used if you are certain they won't penetrate any electrical wires.

- The large screws go through the bottom holes, shorter screws through the top holes. The screws will penetrate wall studs 1" with ½" drywall.
- Secure the frame first using one of the centre holes in the top.
- **For drywall hanging** you must locate the 2" x 4" studs by taping on the wall or with a stud finder. Once located, drill a pilot hole to confirm contact with wood. Do not drill holes too deep. You must have firm contact between wood and screws.

The holes on the frame are 16 inches apart and so should your wall studs. If they are not 16 inches apart you must drill new holes in the frame to match the studs. Each screw should hit the centre of the 2" x 4" stud.

- **For concrete or brick wall hanging** you must mark and drill 8 holes in the wall to match the 8 holes in the frame. Then fasten the frame to the wall using the screws and anchors (not included).



Helpful Tips

- Electrical
 - Each light, filter and heater requires a power supply
 - An outlet directly below one of the corners is recommended

IMPORTANT!

It is the responsibility of the owner and installer to make sure this aquarium is properly supported and secured against falling. The frame should be attached to the wall by a carpenter or qualified person.

The person installing this portrait frame must understand how the wall is constructed and how the electrical wires are run in the wall. A fire could be caused by screwing into an electrical wire.

The manufacturer of this aquarium assumes no liability whatsoever for any accident or water damage caused by this aquarium.